



A23




APU®

PLASTER JOINT PROFILES FOR INTERIOR AND EXTERIOR PLASTERING

Corner bracket **STABILO**

With edge for float-finish plaster



The **APU corner bracket STABILO** is used in interior and exterior plaster systems for forming a flush, exact plaster edge.

The edge of the profile has holes and ribs in the corner area. Where they abut, the corner brackets are connected using the plug connector (Z13).

The corner bracket comes in 3 different edge formations: 12, 15 und 21 mm.



A23



Fitting

- ① Using trimming shears with supporting surface, cut corner bracket to the desired size.
- ② Connect profiles using plug connectors (Z13) provided.
- ③ Fully embed the corner bracket with bonding mortar, creating a flush finish.
- ④ Apply a covering layer of plaster.